



**See what's happening
and have
the power to act.**

Video and security in one

View up to 16 camera

Have total awareness of the property, while fusing video and security into one platform providing a convenient, single user experience

Sound the alarm!

At the touch of the Android Tablet's screen, Home Control HUB lets the user activate the on-site loud, audible sirens that sound for 15 seconds to deter potential intruders

Please note:

The Android Tablet can only be used to control the security system when connected to the same Wi-Fi router. When connected to a different router, only automation and video functions can link.

Basic Function	
CPU	ARM Cortex-A8
CPU max frequency	1300MHz
CPU cores	4
Memory	
System RAM	2GB
Total internal storage	16GB
Storage expansion	MicroSD* (32GB max)
Display	
Resolution	1280 x 800
Refresh rate	55Hz (not included)
Screen size	9.5"
Pixel density	160ppi
Camera	
Rear camera	
Megapixels	8.0
Max picture size	3584 x 2240
Max video size	1920 x 1088
FPS range	5 to 30
Flash	✓
Front camera	
Megapixels	1.9
Max picture size	1600 x 1200
Max video size	1600 x 1200
FPS range	5 to 30
Flash	x
Connectivity	
Wi-Fi wireless	Supports 802.11b/g/n standard
3G	Built-in 3G module
Bluetooth	✓
SIM card support	2x standard size SIM card** slot
USB	High-speed USB 2.0

Award Winning Alarm Systems @ www.cssltd.co.uk

Android Tablet and Home Control HUB app

Your portable command centre



***(Account owners have responsibility for charging)**

Take security control to new levels with the Android Tablet and Home Control HUB app - Your Total Command Centre

Provide unprecedented control over the Home Guard security system, with the Android Tablet and Home Control HUB app. Mounted or mobile around any residential or business property, the Android Tablet allows users to not only surf the web, but open Home Control HUB to action any keypad function. The interface combines the alarm panel, Smart Plug and cameras to control security, automation and video. Delivering a completely unified customer experience

Home Control HUB Android Tablet - CHARGE THE BATTERY Before using the device for the first time. *Charge the device using the USB cable provided with the adapter as charging will be faster when connected to a plug socket via the adapter. Battery full icon is shown when finished if your device is off.